J. KONO^{1,™} G.N. OSTOJIC¹ S. ZARIC¹ M.S. STRANO² V.C. MOORE² J. SHAVER² R.H. HAUGE² R.E. SMALLEY²

Ultra-fast optical spectroscopy of micelle-suspended single-walled carbon nanotubes

¹ Department of Electrical and Computer Engineering, Rice Quantum Institute,

and Center for Nanoscale Science and Technology, Rice University, Houston, Texas 77005, USA ² Department of Chemistry, Rice Quantum Institute, and Center for Nanoscale Science and Technology,

Rice University, Houston, Texas 77005, USA

Received: 14 August 2003/Accepted: 27 October 2003 Published online: 9 March 2004 • © Springer-Verlag 2004

ABSTRACT We present results of wavelength-dependent ultrafast pump-probe experiments on micelle-suspended singlewalled carbon nanotubes. The linear absorption and photoluminescence spectra of the samples show a number of chiralitydependent peaks and, consequently, the pump-probe results sensitively depend on the wavelength. In the wavelength range corresponding to the second van Hove singularities (VHSs) we observe subpicosecond decays, as has been seen in previous pump-probe studies. We ascribe these ultra-fast decays to intraband carrier relaxation. On the other hand, in the wavelength range corresponding to the first VHSs, we observe two distinct regimes in ultra-fast carrier relaxation: fast (0.3-1.2 ps) and slow (5-20 ps). The slow component, which has not been observed previously, is resonantly enhanced whenever the pump photon energy resonates with an interband absorption peak, and we attribute it to interband carrier recombination. Finally, the slow component is dependent on the pH of the solution, which suggests an important role played by H⁺ ions surrounding the nanotubes.

PACS 78.47.+p; 78.67.Ch; 73.22.-f

1 Introduction

Single-walled carbon nanotubes (SWNTs) provide a variety of new opportunities for the exploration of onedimensional (1-D) quantum physics as well as novel device applications. Although their mechanical and electrical properties have been extensively studied during the past decade, there has been only limited success in exploring their optical, magnetic, and magneto-optical properties. In addition to what is commonly expected for excitons in 1-D systems [1-3], SWNTs are expected to show a new class of optical phenomena that arise from their unique tubular structure with varying diameters and chiral angles. Linear and non-linear optical coefficients are expected to be diameter and chirality dependent, and an external magnetic field is expected to induce drastic modifications of their band structure via the Aharonov-Bohm phase [4–7]. Furthermore, non-linear harmonic generation is expected to be highly selective for creating certain orders of high harmonics [8].

🖂 Fax: +7-13/348-5686, E-mail: kono@rice.edu

However, these predicted optical phenomena and properties have not been probed experimentally. This is because in standard production methods SWNTs appear in the form of bundles (or 'ropes') due to their strong van der Waals forces. This 'roping' results in significant broadening of electronic states, smearing out any chirality-dependent features in optical spectra [9-15]. Very recently, a new technique for producing individually suspended SWNTs has been reported [16]. These samples revealed, for the first time, a number of clearly observable peaks in linear absorption and photoluminescence (PL) spectra, corresponding to interband transitions in different types of tubes. A subsequent PL excitation (PLE) spectroscopy study successfully provided detailed peak assignments [17, 18]. These seminal studies have provided opportunities to systematically study other predicted, unique optical properties of SWNTs.

Ultra-fast laser spectroscopy is one of the best methods for measuring carrier distribution functions and relaxation mechanisms. Using a wide variety of techniques employing femtosecond pulses, one can directly examine dynamical processes after creation of electron-hole pairs across the band gap, i.e. carrier dephasing processes, carriercarrier scattering, carrier-phonon scattering, exciton formation, and radiative and non-radiative recombination dynamics. There have been several ultra-fast optical studies of SWNTs [19–22]. Hertel and Moos [19] used ultra-fast photoemission spectroscopy to determine thermalization times in metallic SWNTs to be ~ 200 fs. Three groups [20–22] independently observed subpicosecond to a ps lifetimes for semiconducting SWNTs in pump-probe spectroscopy. Although such ultra-short lifetimes can be expected for intraband relaxation towards the band edge, the microscopic origin of the fast interband decay (which is likely to be non-radiative) is still unclear. One important issue is that these studies were performed on bundled SWNTs, which did not show any PL. It is thus desired to carry out ultra-fast spectroscopy on SWNT samples that show chirality-assigned absorption and PL peaks.

In this article, we report results of a femtosecond pumpprobe study of chirality-assigned SWNTs. The linear absorption and PL spectra of such micelle-suspended SWNT samples show a number of chirality-dependent peaks and, as a result, the pump-probe data sensitively depends on the wavelength used. In the wavelength range corresponding to the second van Hove singularities (VHSs), we observe an ultra-fast (subpicosecond) decay, as has been reported previously [20–22]. We ascribe these ultra-fast decays to intraband carrier relaxation. On the other hand, in the wavelength range corresponding to the first VHSs, we observe *two distinct regimes* in ultra-fast carrier relaxation: fast (0.3-1.2 ps) and slow (5-20 ps). The slow component has not been observed previously, is resonantly enhanced when the pump photon energy matches an absorption peak, and is attributed to interband carrier recombination. The slow component is also strongly dependent on the pH of the solution, especially in large-diameter tubes.

2 Samples studied

The SWNTs studied in the present work were dispersed in aqueous sodium dodecyl sulfate (SDS) surfactant, sonicated, and centrifuged, which left micelle-suspended nanotube solutions. Details of the sample-preparation method were described previously [16].

Typical linear absorption and PL spectra for such micellesuspended SWNTs are shown in Fig. 1b, together with a schematic density of states vs. energy of semiconducting SWNTs in Fig. 1a. The PL peaks occur in the near infrared ($\sim 0.9-1.4 \text{ eV}$) and are due to transitions involving the first conduction (E_1) and valence (H_1) subbands. The absorption spectrum shows peaks from the near-infrared to the visible range, consisting of three overlapping bands: E_1H_1 transi-



FIGURE 1 a Schematic density of states vs. energy for a semiconducting carbon nanotube. **b** Typical linear absorption (*solid line*) and photoluminescence (*dashed line*) spectra of SDS-suspended single-walled carbon nanotubes in heavy water (pH = 9) at room temperature. The photoluminescence was excited at 733 nm

tions in semiconducting tubes (0.78–1.55 eV), E_2H_2 transitions in semiconducting tubes (1.38–2.26 eV), and transitions in metallic tubes (2.07–3.11 eV). Detailed analyses and interpretations of these linear absorption/emission features are described in [17, 18].

3 Experimental setup

We performed wavelength-dependent, degenerate pump-probe measurements using \sim 150-fs pulses from an optical parametric amplifier (OPA) pumped by a chirped pulse amplifier (CPA) (Clark-MXR CPA2010). We used a low pulse-repetition rate (1 kHz) for minimizing the average power and reducing any thermal effects while keeping the fluence high. To detect small photoinduced changes in probe transmission, we synchronously chopped the pump beam at 500 Hz and measured the transmission with (T) and without (T_0) the pump using two different gates of a box-car integrator. The smallest detectable differential transmission (T - T) $T_0)/T_0 \equiv \Delta T/T_0$ was $\sim 10^{-4}$. We used a noncollinear geometry with a pump-beam diameter of \sim 220 µm in the overlap area. We tuned the OPA throughout the range of first subband transitions (i.e. E_1H_1 transitions; see Fig. 1) with photon energies $h\nu = 0.8 \text{ eV}$ to 1.13 eV (wavelengths $\lambda = 1.1 \,\mu\text{m}$ to $1.55 \,\mu\text{m}$). In addition, by directly using the CPA beam $(h\nu = 1.60 \text{ eV}, \lambda = 775 \text{ nm})$, we probed a region of second subband transitions (E_2H_2) .

4 Experimental results

4.1 First vs. second subband excitations

Figure 2 shows typical differential transmission $(\Delta T/T_0)$ data as a function of time delay. Two traces are shown, taken at 0.89 eV (1393 nm) and 1.60 eV (775 nm), corresponding to E_1H_1 and E_2H_2 ranges, respectively (refer to



FIGURE 2 Ultra-fast pump-probe data at two wavelengths, corresponding to first and second subband transitions. A very fast single decay is seen in the second subband case while two decay components (τ_1 and τ_2) are clearly seen in the first subband case. *Solid lines* show Gaussian and exponential fits in the appropriate delay regimes

Fig. 1). Both show a positive change (or an increase) in transmission, i.e. photoinduced bleaching, which is consistent with band filling. An exponential fit reveals a fast, single decay time of 770 fs for the E_2H_2 transition, which is consistent with earlier reports and can be explained by the very fast intraband carrier relaxation towards the band edge [22]. On the contrary, data in the range of E_1H_1 transitions exhibit *multiple exponential decays*. The major decay of the photoinduced signal happens in the first picosecond (with decay time τ_1), which is followed by a much slower relaxation process. For the particular data shown in Fig. 2, we obtained an exponential decay time of $\tau_2 \approx 10$ ps. This long decay time has not been reported previously for either metallic [19] or semiconducting SWNTs [20–22].

4.2 Pump fluence dependence

For both first and second subband transitions, the pump fluence dependence of the maximum value of $\Delta T/T_0$ reveals clear saturation at high fluences, as shown in Fig. 3. This implies that, in the saturation regime, most of the carrier states are filled and thus the sample absorption is nearly completely quenched. A careful analysis of the differential transmission decays for the hv = 0.89-eV case showed that relaxation dynamics are not dependent on the pump fluence, including the saturation regime. As an example, in Fig. 4 we show pump–probe data at a wavelength of 1402 nm for four different pump fluences. This precludes the possibility of any non-linear recombination process such as Auger recombination.

4.3 Resonant vs. non-resonant excitations

To study any differences between resonant and non-resonant excitations in carrier relaxation as well as any diameter- and/or chirality-dependent phenomena, we scanned the photon energy from 0.8 eV to 1.1 eV, corresponding to the E_1H_1 transitions of 0.82–1.29-nm-diameter tubes [17]. For all the photon energies, the pump fluence



FIGURE 3 The pump fluence dependence of the maximum photoinduced transmission change at the two wavelengths corresponding to the two traces in Fig. 2. In both cases clear saturation is seen



FIGURE 4 Power-dependent pump-probe spectroscopy data taken at a wavelength of 1402 nm (or a photon energy of 0.884 eV). The decay dynamics do not show any power dependence, excluding any non-linear recombination mechanisms

was kept constant at 1 mJ/cm^2 , which is below the saturation regime (see Fig. 3). Figure 5a shows the linear absorption spectrum in the E_1H_1 transition range. The photon energies at which we performed pump-probe measurements are labeled 1–16, covering both peaks and valleys in absorption. Figure Fig. 5b shows the maximum value of $\Delta T/T_0$ as a function of photon energy; it loosely follows the absorption curve in Fig. 5a. Also shown in Fig. 5b (right vertical axis) is the ratio of the slow component (defined as $\Delta T/T_0$ at 5 ps) to the fast component (defined as $\Delta T/T_0$ at 0 ps) as a function of photon energy; it also follows the absorption curve in Fig. 5a, indicating that the slow component is resonantly enhanced at absorption peaks.

To demonstrate this more directly, eight traces of differential transmission dynamics taken at different photon energies are shown in Fig. 6a–h. The chosen photon energies correspond to the peaks and valleys in the linear absorbtion data in Fig. 5a, marked as 2, 3, 4, 6, 7, 8, 11, and 13. For the photon energies corresponding to peaks in linear absorption [(a), (c), (e), and (g)], the chirality indices (n, m), assigned through PL excitation spectroscopy [17, 18], are (a): (10, 2), (c): (12, 1) and (8, 6), (e): (10, 3) and (10, 5), and (g): (11, 4). The slow component is clearly observable for the photon energies corresponding to absorption peaks [(a), (c), (e), and (g)] while the traces corresponding to valleys [(b), (d), (f), and (h)] show only the initial, fast decay.

4.4 *pH dependence*

By adjusting the pH of the solution via adding NaOH or HCl, we found that pump–probe dynamics are strongly dependent on the pH and the dependence is stronger at longer wavelengths (or larger tube diameters). Specifically, we observed that the slow component drastically diminishes as the pH is reduced. Examples are shown in Fig. 7. As pre-



FIGURE 5 a Linear absorption in the E_1H_1 range. The numbers (1–16) correspond to the 16 photon energies at which pump–probe measurements were made. **b** The peak value of $\Delta T/T_0$ (*left-hand axis*) and the ratio of slow to fast components (*right-hand axis*) vs. photon energy

viously reported [23], adding hydrogen ions, H⁺, to the solution (or, equivalently, decreasing the pH value) diminishes, and finally collapses, linear absorption and PL peaks. This effect starts from the longer-wavelength side, i.e. from largerdiameter tubes. The corresponding reduction and disappearance of the slow component show exactly the same trend, as shown in Fig. 7. For example, at $h\nu = 1.118$ eV (or $1.11 \,\mu$ m), there is almost no change in pump-probe dynamics from pH = 5.5 to pH = 4.5 (see Fig. 7a). However, as the photon energy is decreased to 0.906 eV [b], 0.879 eV [c], and 0.853 eV [d], the disappearance of the slow component becomes increasingly more drastic. Figure 8a-c show, respectively, the pH dependence of (a) near-infrared absorbance spectra in the E_1H_1 energy range, (b) the maximum value of the differential transmission, and (c) the ratio of the slow component $(\Delta T/T_0)$ at 3 ps) to the fast component ($\Delta T/T_0$ at 0 ps) as functions of photon energy. It is clearly seen that all the three quantities decrease with decreasing pH, and the decrease is more significant at longer wavelengths (or wider-diameter tubes).

5 Discussion

As we presented in Sect. 4, our wavelengthdependent single-color pump-probe spectroscopy data on micelle-suspended SWNTs revealed two different decay components, suggesting two different carrier relaxation processes. One component is fast (0.3-1.2 ps) and the other is slow (5-20 ps). In the following we discuss possible origins



FIGURE 6 Wavelength-dependent (one-color) pump–probe spectroscopy data, corresponding to the photon energies labeled #2, #3, #4, #6, #7, #8, #11, and #13 in Fig. 5a, covering both absorption peaks and valleys. For the energies corresponding to absorption peaks [(a), (c), (e), and (g)], the chirality indices (*n*, *m*) of the SWNTs probed at those energies are (a): (10, 2), (c): (12, 1) and (8, 6), (e): (10, 3) and (10, 5), and (g): (11, 4)

of these two dynamical processes as well as the intriguing pH dependence of the pump–probe data we obtained.

Both the positive sign of the differential transmission and the initial ultra-fast (< 1 ps) relaxation agree with the recent reports for semiconducting SWNTs [20–22]. The positive sign can be interpreted as state filling as the cause of the photo-bleaching signal and is consistent with the saturation at high fluences (Fig. 3). Namely, the pump-induced





FIGURE 7 pH-dependent pump–probe data for different wavelengths. The pH dependence becomes stronger for smaller photon energies, corresponding to larger-diameter SWNTs

carriers fill states and reduce the probe absorption. We believe that the ultra-fast decay mechanism is non-radiative (i.e. phonon and/or impurity mediated) and intraband. It is likely to be non-radiative because this signal exists even for samples that do not luminesce [20-22]. It is likely to be intraband relaxation (as opposed to interband relaxation) since it exists both in resonant and non-resonant cases. Note that even when the photon energy is resonant with the E_1H_1 absorption peak of a particular tube type, it creates nonresonant carriers in other types of tubes whose band gaps are smaller than that of the resonant tube. Note also that we are not seeing any pump-power-dependent decay times, as shown in Fig. 4, which precludes carrier-density-dependent non-radiative processes such as Auger recombination as the origin of the fast decay component. In addition, it is likely that there is some coherent contribution to the pump-probe signal in this ultra-short time scale. However, since we have not observed any four-wave-mixing signal, we do not have an estimate of the dephasing time and thus will not discuss how large this contribution is.

On the other hand, the slow decay signal, which was resonantly enhanced when the photon energy coincided with an interband absorption peak, has not been reported previously.

FIGURE 8 pH dependence of **a** near-infrared absorbance in the E_1H_1 energy range, **b** maximum value of the differential transmission, and **c** the ratio of the slow component ($\Delta T/T_0$ at 3 ps) to the fast component ($\Delta T/T_0$ at 0 ps) as a function of photon energy

We interpret this slow component as interband carrier recombination. Note that in bundled samples band edges are not well defined for individual tubes due to electronic coupling, and thus photo-created carriers cannot show clear interband dynamics in pump-probe measurements. In other words, there is no clear distinction between intertube dynamics and intraband dynamics in bundled tubes because van Hove singularities of different tube types form a van Hove absorption band. We further argue that the slow component we observed is probably related to radiative recombination. An important fact for supporting this claim is that in the previous work no PL was observed, whereas our sample exhibits PL peaks at the same energies as E_1H_1 absorption peaks (see Fig. 1). In addition, reducing the pH of the solution destroys PL and absorption peaks while at the same time the slow decay vanishes (see Fig. 7), indicating an intimate relationship between PL and the slow decay signal. The actual value of the radiative recombination lifetime τ_r depends on the value of the radiative efficiency (or quantum yield) $\eta = \tau_r^{-1}/(\tau_r^{-1} + \tau_{nr}^{-1})$, where τ_{nr} is the non-radiative lifetime, since what we measure experimentally is the *total* decay rate, $\tau^{-1} = \tau_r^{-1} + \tau_{nr}^{-1}$. Direct measurements of τ_r through time-resolved PL are in progress.

Finally, we propose possible scenarios for the drastic pH dependence we observed. Decreasing the pH leads to an increase in the density of H⁺. First, adsorbed H⁺ ions on the nanotube surface could add a relaxation channel by the creation of ultra-fast carrier trapping centers (defects). This should make the fast non-radiative recombination dominant over the slower radiative recombination if the density of such trapping centers is high. In addition, as previously noted, H⁺ ions effectively act as acceptors in SWNTs, and thus the Fermi energy $(E_{\rm F})$ depends on the H⁺ density. When the density is so high that $E_{\rm F}$ lies inside the valence band, interband absorption peaks disappear, irrespective of whether the peaks are due to excitons or van Hove singularities. This can be viewed as a 1-D manifestation of the well-known Burstein-Moss effect [24, 25]. Larger-diameter tubes are expected to have smaller acceptor binding energies due to their smaller effective masses, and thus should be more susceptible to pH changes. In a heavy-doping regime, there is a degenerate hole gas in the valence band, which can completely quench excitonic processes.

6 Summary

In summary, we have carried out an ultra-fast optical study of micelle-suspended single-walled carbon nanotubes. We have observed two relaxation regimes in the dynamics of micelle-suspended single-walled carbon nanotubes under resonant excitations. We interpret the previously observed shorter decay time τ_1 as non-radiative intraband relaxation and the previously unobserved larger decay time τ_2 as related to radiative interband recombination. The overall relaxation of photoexcited carriers can be made faster by increasing the density of H⁺ ions in the solution, while simply increasing the number of photoexcited carriers does not change the dynamics. The sensitive pH dependence provides a novel means to chemically control carrier states and dynamics in nanotubes. ACKNOWLEDGEMENTS This work was supported by the Robert A. Welch Foundation (Grant No. C-1509), the Texas Advanced Technology Program (Project No. 003604-0001-2001), and the National Science Foundation CAREER Award (Grant No. DMR-0134058).

REFERENCES

- 1 R. Loudon: Am. J. Phys. 27, 649 (1959)
- 2 R.J. Elliot, R. Loudon: J. Phys. Chem. Solids 8, 382 (1959)
- 3 T. Ogawa, T. Takagahara: Phys. Rev. B 43, 14325 (1991)
- 4 H. Ajiki, T. Ando: J. Phys. Soc. Jpn. **62**, 1255 (1993)
- 5 H. Ajiki, T. Ando: J. Phys. Soc. Jpn. 62, 2470 (1993)
- 6 W. Tian, S. Datta: Phys. Rev. B 49, 5097 (1994)
- 7 J.P. Lu: Phys. Rev. Lett. 74, 1123 (1995)
- O.E. Alon, V. Averbukh, N. Moiseyev: Phys. Rev. Lett. 85, 5218 (2000)
 H. Kataura, Y. Kumazawa, Y. Maniwa, I. Umezu, S. Suzuki, Y. Ohtsuka, Y. Achiba: Synth. Met. 103, 2555 (1999)
- 10 M. Ichida, S. Mizuno, Y. Tani, Y. Saito, A. Nakamura: J. Phys. Soc. Jpn. 68, 3131 (1999)
- 11 S. Kazaoui, N. Minami, R. Jacquemin, H. Kataura, Y. Achiba: Phys. Rev. B 60, 13 339 (1999)
- 12 A. Ugawa, A.G. Rinzler, D.B. Tanner: Phys. Rev. B 60, R11 305 (1999)
- 13 S. Kazaoui, N. Minami, H. Yamawaki, K. Aoki, H. Kataura, Y. Achiba: Phys. Rev. B 62, 1643 (2000)
- 14 J. Hwang, H.H. Gommans, A. Ugawa, H. Tashiro, R. Haggenmueller, K.I. Winey, J.E. Fischer, D.B. Tanner: Phys. Rev. B 62, R13310 (2000)
- 15 R. Saito, H. Kataura: in Carbon Nanotubes: Synthesis, Structure, Properties, and Applications (Springer, Berlin 2001) pp. 216–250
- 16 M.J. O'Connell, S.M. Bachilo, C.B. Huffman, V.C. Moore, M.S. Strano, E.H. Haroz, K.L. Rialon, P.J. Boul, W.H. Noon, C. Kittrell, J. Ma, R.H. Hauge, R.B. Weisman, R.E. Smalley: Science **297**, 593 (2002)
- 17 S.M. Bachilo, M.S. Strano, C. Kittrell, R.H. Hauge, R.E. Smalley, R.B. Weisman: Science 298, 2361 (2002)
- 18 R.B. Weisman, S.M. Bachilo: Nano Lett. 3, 1235 (2003)
- 19 T. Hertel, G. Moos: Phys. Rev. Lett. 84, 5002 (2000)
- 20 Y.C. Chen, N.R. Raravikar, L.S. Schadier, P.M. Ajayan, Y.P. Zhao, T.M. Lu, G.C. Wang, X.C. Zhang: Appl. Phys. Lett. 81, 975 (2002)
- 21 H. Han, S. Vijayalakshmi, A. Lan, Z. Iqbal, H. Grebel, E. Lalanne, A.M. Johnson: Appl. Phys. Lett. 82, 1458 (2003)
- 22 J.S. Lauret, C. Voisin, G. Cassabois, C. Delalande, Ph. Roussignol, O. Jost, L. Capes: Phys. Rev. Lett. 90, 057404 (2003)
- 23 M.S. Strano, C.B. Huffman, V.C. Moore, M.J. O'Connell, E.H. Haroz, J. Hubbard, M. Miller, K. Rialon, C. Kittrell, S. Ramesh, R.H. Hauge, R.E. Smalley: J. Phys. Chem. B 107, 6979 (2003)
- 24 E. Burstein: Phys. Rev. 93, 632 (1954)
- 25 T.S. Moss: Proc. Phys. Soc. B 67, 775 (1954)